

Installation Instructions

To turn on the wireless mini light bar, press the power button located on the top of the unit. Pressing the same button will cycle through the available flash patterns.

To turn off the wireless mini light bar, press and hold the power button for three (3) seconds. When the unit is powered on again, it will automatically resume the previously selected flash pattern.

Once the light bar is turned on, the power button's adjacent light will show the battery level, as per Chart 1.

To prevent any damage from dirt or moisture, it is imperative to make sure the charging port plug is fully inserted during the procedure.

Charging the Wireless Light Bar

To use the wireless light bar, it should be charged first. Follow the steps below to charge the unit:

1. At the connector at the bottom of the light bar, unplug the plug.
2. Before connecting it to a suitable auxiliary power connection in your car, plug the power cord into the connector.
3. Wait for the device to charge completely, which should take around 4.5 hours.
4. As illustrated in Chart 1, check the light next to the power button to see if it is charging. After the charging is done, the light will turn green.

After the charging is complete, follow the steps below to protect the light bar from moisture and dirt:

1. Disconnect the connector's power cord.
2. Make sure the charging connector's charging connector has the sealing plug fully inserted.

By following these steps, you can ensure that your wireless light bar is fully charged and protected from dirt and moisture.

Using the Wireless Remote

You can use the wireless remote to turn the light bar on or off. To turn the light bar off or on again, follow these steps:

1. Locate the remote control.
2. Press the power button on the remote control to turn the light bar off or on.

To select the flash pattern using the wireless remote, follow these steps:

1. Locate the mode button on the remote control.
2. Press the mode button to select the next flash pattern, as shown in Chart 2.

Pairing the Remote with the Wireless Mini Light Bar

To pair the remote with the wireless mini light bar, please follow these steps:

1. Carefully turn off the light bar. Push and hold the power button on the light bar for a brief period of time until the green light next to the button starts flashing, then press and release the power button once more.
2. On the remote control, press the power button. The green light will change to red and will flash.
3. On the remote, press the mode button. A steady green light will replace the flashing red light as the following flash pattern is chosen.
4. Use the remote as normal. Press the power button to turn the device on or off. To choose the flash pattern, press the mode button.

To pair a second light bar with the same remote, simply repeat the above steps with the second light bar.

Both light bars should now be paired with the remote and respond to its commands.



Chart 1

STATUS	LEVEL	LIGHT INDICATION
In Use	0-9%	Flashing Red
	10-29%	Red
	30%-69%	Yellow
	70%-100%	Green
Charging	0-29%	Flashing Red
	30%-69%	Flashing Yellow
	70%-99%	Flashing Green
	100%	Green

Chart 2 - Flash Patterns

NUMBER	PATTERN
1	single flash
2	double flash
3	triple flash
4	quad flash
5	Quint flash
6	clockwise chase
7	counterclockwise chase